

Yealink Auto Provisioning with Calncall User guide

There is two ways to do Yealink (SIP-T20P & SIP-T21P) auto provisioning with Calncall.


A. Using Phone:

Step 1 : First you will need to factory reset the phone.

Press & hold the “ok” button till the phone prompts the message “Reset to factory?” and press “ok” again to reboot.

Step 2 : Go to Advanced settings on the phone.


Press ‘Menu’ button and then select settings→Advanced settings



Step 3 : Enter the default password “admin” and press confirm



Step 4 : Select “Auto Provision” and Enter “pro.calncall.com” then save and reboot.




B. Using Web Interface:

Step 1 : Press “ok” button on the phone then you will see IP address Ex. 192.168.xxx.xxx.



Step 2 : Enter the IP address on browser(Firefox or Chrome) .(Both IP phone & computer should be connected same LAN)



Step 3 : Enter the default Username & Password

Username : admin

Password : admin

Step 4 : Go to Settings→Auto Provision→Enter provision server URL : pro.calncall.com
Then Click “Autoprovision Now”

The screenshot shows the Yealink T22 web interface. The top navigation bar includes tabs for Status, Account, Network, DSSKey, Features, and Settings (highlighted). The left sidebar lists various configuration categories, with 'Auto Provision' highlighted. The main content area displays the 'Auto Provision' settings, including options for PNP Active, DHCP Active, Custom Option, DHCP Option Value, Server URL (set to pro.calncall.com), User Name, Password, Common AES Key, MAC-Oriented AES Key, Zero Active, Wait Time, Power On, Repeatedly, Interval, Weekly, Time, and Day of Week. The 'Autoprovision Now' button is highlighted at the bottom right.

Step 5 : Click ‘Ok’ then IP Phone will reboot and is now ready to use.

The screenshot shows a browser dialog box with the text "The page at 192.168.7.155 says:" and "Do you want to auto provision now?". There are two buttons: "OK" (highlighted) and "Cancel".